

120 VOLTS		
CATALOG NUMBER	LENGTH	WATTS*
RC30	30' (9 m)	150
RC60	60' (18 m)	300
RC80	80' (24 m)	400
RC100	100' (31 m)	500
RC120	120' (37 m)	600
RC160	160' (49 m)	800
RC200	200' (61 m)	1000
RC240	240' (73 m)	1200
ACCESSORIES		
CSPI	Replacement Clips & Spacers	



www.frostking.com

420 Route 17 South
Mahwah NJ

465 East Glendale Avenue
Sparks NV 89431

Tel 800/526-5265 Fax 201/684-1214



Electric Roof De-icing Cable

Stop Damaging Roof-Ice Buildup

MEASURE

- Horizontal length of each roof section to be protected, in feet.....
- Depth of overhang for each roof section, in inches.....
- Each dormer — up, over and down — per diagram, in feet.....
- Length of each downspout, in feet.....
- Note number of roof intersection valleys.....

CALCULATION BY SECTION

- For each section overhang depth, find the multiplier table.....
- If the section has no gutter, subtract 1.0 from the multiplier.....
- Multiply length of each roof section by its overhang multiplier.....
- Total all the section dormer measurements.....
- For each downspout with cable running down and back up, typically all but the last one in a cable run, multiply length by 2 and add together.....
- Total length of downspouts with cables running down only, typically the last one in a cable run.....
- Multiply the number of valleys by 6.....

TOTAL ITEMS C-G

Frost King products are provided with a LIMITED WARRANTY; see owner's manual or contact Frost King for complete terms and conditions.



- PREVENT ROOF DAMAGE AND LEAKING
- KEEP GUTTERS & DOWNSPOUTS FLOWING
- PREASSEMBLED READY-TO-INSTALL

